

## **Lucite Fallboard Lock Instructions (#205)**

This “hands-off reserved for performance” kit includes lock and shoe, keys, spacers, double-stick tape and screws.

The lock was designed to fit pianos with dimensions of 6" or less from top of fallboard to bottom of key bed. Extra space can be obtained by mortising the shoe into underside of key bed.

Decide if you need to use spacers. It is best that top of locking device is very close to top of fallboard.

1. Mount unit under key bed at bass end of piano. Be sure to allow for removal of cheek block and/or key slip screw.
2. Hold lock in position to make sure it will engage properly. Apply tape to shoe or spacer. Install 4 screws to fasten shoe / spacer to key bed.

The hardened screws that are included, will not need a pilot hole, unless the key bed is made of very hard wood.

- Easy installation
- Does not touch finished surfaces of piano
- Manufactured with a high-quality pin tumbler lock and two keys
- Can be keyed alike - Specify with order
- Used in schools, auditoriums, hotels, churches and concert halls

