




# J4004 Adjustable Digital Dolly Assembly Instructions

**CAUTION: Do not overtighten setscrews!**

**Adjustable Width 47" - 68"**



**Adjustable Depth 15 - 22"**